



ISTITUTO ITALIANO  
DI TECNOLOGIA

# Joint Level Motor Control

Lorenzo Natale

iCub Facility

Istituto Italiano di Tecnologia, Genova, Italy

**Note:** extracted from <https://github.com/vvv-school/vvv18/blob/master/material/yarp/vvv18-yarp-motor-control.pdf>



ISTITUTO ITALIANO  
DI TECNOLOGIA

# Joint Level Motor Control


(for whole-body dynamic control)

Silvio Traversaro

iCub Facility


Istituto Italiano di Tecnologia, Genova, Italy

# Position Direct




**Note:** extracted from <https://github.com/vvv-school/vvv18/blob/master/material/yarp/vvv18-yarp-motor-control.pdf>

# Position Control



**Note:** extracted from <https://github.com/vvv-school/vvv18/blob/master/material/yarp/vvv18-yarp-motor-control.pdf>


# Velocity Control



**Note:** extracted from <https://github.com/vvv-school/vvv18/blob/master/material/yarp/vvv18-yarp-motor-control.pdf>

# Torque Control (iCub, Feb 2018)

## iCub Low Level Control for Gravity Compensation




# Interface: ITorqueControl

Like IPositionControl2 and  
IVelocityControl2, but for torque  
control

```
ITorqueControl::getAxes() = 0;  
ITorqueControl::setRefTorque(...) = 0;  
ITorqueControl::getTorque(...) = 0;
```

# Hardware abstraction



/icubSim/left\_arm/rpc:i  
/icubSim/left\_arm/state:i  
/icubSim/left\_arm/command:o

/client/left\_arm/rpc:i  
/client/left\_arm/state:i  
/client/left\_arm/command:o



# Getting Interfaces

Devices are opened by mean of a special class called “PolyDriver”.

PolyDriver is a polymorphic class which can turn into any device.

Keyword “device” tell YARP which device we really want to open.

All other parameters will be propagated to the specified device.

Device devoted to provide remote access to the robot motor control is the “remote\_controlboard”

Required parameter to configure it are:

- Remote port prefix: remote
- Local port name: local

```
PolyDriver poly;
```


```
Property config;
```

```
config.put("device", "remote_controlboard");  
config.put("remote", "/icub/head");  
config.put("local", "<myApplication>");  
...
```

```
poly.open(config);
```

**Note:** extracted from <https://github.com/vvv-school/vvv18/blob/master/material/yarp/vvv18-yarp-motor-control.pdf>

# Whole-body hardware abstraction



The remapper only exposes the joint required by the user application.  
Similar concept in `ros_control` : **CombinedRobotHW**

# Getting Interfaces only for the desired joints

The device that combines multiple “remote\_controlboard” devices by specifying the desired joints is “remotecontrolboardremapper”

Required parameter to configure it are:

- List of remote port prefixes: remoteControlBoards
- Local port name: localPortPrefix
- Ordered list of desired joints: axesNames

```
PolyDriver poly;  
Property config;  
  
config.put("device", "remotecontrolboardremapper");  
config.put("localPortPrefix", "<myApplication>");  
  
Bottle boards;  
Bottle & boardsList = boards.addList();  
boards.addString("/icubSim/torso");  
boards.addString("/icubSim/left_arm");  
boards.addString("/icubSim/right_arm");  
options.put("remoteControlBoards", boards.get(0));  
  
Bottle joints;  
Bottle & jointsList = joints.addList();  
joints.addString("torso_pitch");  
...  
joints.addString("r_wrist_yaw");  
options.put("axesNames", joints.get(0));  
  
...  
  
poly.open(config);
```

```
ITorqueControl *trqControl = NULL;
poly.view(trqControl);           // Get the interface

int joints;
trqControl->getAxes(&joints);     // Get number of joints

yarp::sig::vector desTorques(joints, 0.0);
trqControl->setRefTorques(desTorques.data()); // Set a desired torques setpoint

yarp::sig::vector measTorques(joints, 0.0);
trqControl->getTorques(measTorques.data());  // Get the measured (or estimated) torques
```